
ALTERNATOR, 50A
#10 ORN
#14 BRN
CIRCUIT BREAKER
20 AMP
SPARK PLUGS
FUEL SOLENOID
FUEL LIFT PUMP
DISTRIBUTOR
OIL PRESS. SWITCH
WATER TEMP. SWITCH
EXHAUST TEMP. SWITCH
BATTERY SWITCH
STARTER
12 VDC
GROUND TO BLOCK
CHOKE SOLENOID
OPTIONAL
OIL PRESSURE SENDER
WATER TEMP. SENDER
#16 RED/WHT
#16 RED/VIO
#12 RED
#16 LT. BLUE
#16 TAN
#14 VIO
#14 BLK
#16 WHT/YEL
#12 YEL/RED
#16 ORG
#16 RED
#16 WHT/YEL
#16 VIO
#16 BLK
#16 WHITE
#16 BLACK
FUSE 1 8 AMP
START / STOP SWITCH
ON SWITCH
HOUR METER
TB1
TB2
1N4002
K1
K2
CKT 1
CKT 2
FOR CONNECTIONS TO REMOTE START AND REMOTE INSTRUMENT PANELS, SEE DRAWINGS 43912, 35706, 35698.
TB2-1
TB1-5
TB1-4
TB1-2
TB2-3
TB1-1
TB1-6
TB2-2
T1 T2 T3 T4 T5
OVERSPEED CIRCUIT
12 VDC BATTERY
BATTERY SWITCH
STARTER SOLENOID
STARTER
ALTERNATOR
TB2-4
HOURMETER
FUEL SOL.
FUEL PUMP
DISTRIBUTOR
20 AMP CIRCUIT BREAKER
F1 8 AMP
OIL PRESS. SWITCH
WATER TEMP SWITCH
EXHAUST TEMP SWITCH
OVERSPEED SWITCH
STOP SWITCH CKT 1
K2-RUN
K1-START
ON SWITCH
START SWITCH CKT 2
CHOKE SOL.
OIL PRESSURE SENDER (OPTIONAL)
WATER TEMP SENDER (OPTIONAL)
TB2-1
TB2-2
TB1-1
TB1-2
TB2-3
TB1-5
TB1-4
TB1-6(TB2-5)
SEE NOTE 1
LED
REMOTE PANEL CONNECTIONS #35706 AND #35698
REMOTE PANEL CONNECTIONS #43912
NOTES:
1. REMOVE JUMPER BETWEEN TB1-1 AND TB1-2 WHEN USING A REMOTE PANEL.
DENOTES REMOTE CONNECTOR PIN NUMBERS
TOLERANCES
WESTERBEKE CORPORATION
TAUNTON MA, 02780
WIRING DIAGRAM
GASOLINE GENSETS
NONE
E
46094