



- NOTES:
1. REMOVE JUMPER WHEN CONNECTING A SECOND REMOTE PANEL.
 2. GROUND "1" TERMINAL OF PREHEAT SOLENOID ON 24V SYSTEM ONLY.
 3. ○ REMOTE CONNECTOR PINS.
 4. THE 5K REMOTE SPEED POTENTIOMETER CAN BE WIRED TWO DIFFERENT WAYS:
 1. AS SHOWN BY THE SOLID LINE FROM THE WIPER OF THE 5K POTENTIOMETER AND THEN CONNECTED TO TERMINAL 9 (NO RESISTOR REQUIRED). ADJUSTABLE RANGE IS APPROXIMATELY ±5% AT 1800 RPM.
 2. AS SHOWN BY THE DASHED LINE FROM THE WIPER OF THE 5K POTENTIOMETER THROUGH RESISTOR "R" AND THEN CONNECTED TO TERMINAL 8, REDUCING THE VALUE OF "R" INCREASES THE REMOTE ADJUSTABLE SPEED RANGE.

TOLERANCES		WESTERBEKE CORPORATION	
UNLESS OTHERWISE SPECIFIED		TAUNTON, MA, 02780	
INCHES	MILLIMETERS	TITLE	
±.0005	±.0125	WIRING DIAGRAM/SCHEMATIC	
±.001	±.025	MARINE GENERATOR - PARALLEL	
±.002	±.050	DATE	REV.
±.005	±.125	APPROVED BY	DATE
±.010	±.250	SCALE NONE	SIZE
±.015	±.375	INCHES	NUMBER
±.020	±.500	FEET	REV.
±.030	±.750	NO. 1 OF 1	E 48350